

DT17C Clock Set

Press and hold the time set button.

Press the day button for the present day.

Press hour and min. button for the present time.

Programming

1, Press mode button to auto.

2, Press program Button.

3, Press day button for the on day or days you need.

4, Press hour and min. button for you're on time.

5, Press the on/off button for you're off time.

6, Press day button for the off day or days you need.

7, Press hour and min. button for you're off time.

8, Repeat steps, 2 through 7 if you need more programs.

9, Press the time set button, or wait 15 seconds to exit programming. You're done.